

Parts List — SR5099

Part Number	Description	Config Step	Qty
250876	MANUAL, OPERATORS – SR - STAGE 1	Configuration Type	1
417000	BDL, SINGLE RANK SR6015	Tank Configuration	1
270225	SCALE, DIGITAL - HANDHELD	Tank Configuration	1
419095-1	BDL, RESIDUE WHEEL - SPLIT BUSHI 6015 SR - STAGE 3	Tank Configuration	1
419096	BDL, OPENER HOSE HOLDERS SB - SR	Tank Configuration	1
400532	BDL, HD FERT KNIFE - SR	Tank Configuration	1
419093	BDL, OPENERS - SR6015 - INLINE	Opener Configuration	1
400678	BDL, SEED KNIFE IL OFFSET RIGHT - SR	Opener Configuration	48
400679	BDL, SEED KNIFE PAIRED ROW - SR	Opener Configuration	48
404139	BDL, NH3 DROP TUBE	Liquid Drop Tubes	48
270132	KIT, IN-CAB - VIPER 4+ - No GPS	Raven Monitor	1
270155	CODE, UNLOCK VIPER 4 COMBO VRA (SINGLE+MULTI)	VRA Unlock Code	1
412710	ASSY, CAN ROLL-12 RUN UPII	Top Meter - Canola Roller	1
419400	BDL, HITCH - REAR - SR15 - STAGE 1	Rear Hitch Option	1